



## B737 Component Support Capabilities

Derco Repair Services, Inc.  
 8065 West Fairlane Avenue Milwaukee, WI 53223 USA  
 tel: (414) 355-7770; fax: (414) 355-2648  
 repair@dercoaerospace.com

PART NUMBER	DESCRIPTION	MANUFACTURER	ATA
102650EF	MOTOR, DC, ELECTRICAL	ITT AEROSPACE	24
102650EZ	MOTOR, DC, ELECTRICAL	ITT AEROSPACE	24
102842DJ	VALVE, FUEL, SHUTOFF	ITT AEROSPACE	28
10-60496-2	FAN, VANEAXIAL	BOEING	21
10-60508-3	VALVE, CHECK	BOEING	36
106785A105	MOTOR, DC	ITT AEROSPACE	24
106785B101	MOTOR, DC	ITT AEROSPACE	24
106785B105	MOTOR, DC	ITT AEROSPACE	24
106788A103	ACTUATOR, ROTARY	ITT AEROSPACE	24
106788A128	ACTUATOR, ROTARY	ITT AEROSPACE	24
106788A131	ACTUATOR, ROTARY	ITT AEROSPACE	24
106788A140	ACTUATOR, ROTARY	ITT AEROSPACE	24
106892-1-1	TUBE, FLOW SENSING	HONEYWELL	36
11-0283-3	LIGHT, EMERGENCY EXIT	GRIMES	33
123558-1-1	VALVE, CHECK	HONEYWELL	36
123558-1-3	VALVE, CHECK	HONEYWELL	36
123558-1-4	VALVE, CHECK	HONEYWELL	36
12D124-9	VALVE	AAR	38
1356-603399	ACCUMULATOR, HYDRAULIC	PARKER	29
140-025-1	TRANSDUCER, WHEEL SPEED	CRANE/HYDRO-AIRE	32
140-025100	TRANSDUCER, WHEEL SPEED	CRANE/HYDRO-AIRE	32
140-025101	TRANSDUCER, WHEEL SPEED	CRANE/HYDRO-AIRE	32
140-025-2	TRANSDUCER, WHEEL SPEED	CRANE/HYDRO-AIRE	32
16006-001	PUMP, LAVATORY	MONOGRAM	38
2CM9ABY7	GENERATOR, TACHOMETER	AMETEK	77
30-0837-1	LIGHT, STROBE	GRIMES	33
30-0837-11	LIGHT, STROBE	GRIMES	33
30-0837-13	LIGHT, STROBE	GRIMES	33
30-0837-15	LIGHT, STROBE	GRIMES	33
30-0837-17	LIGHT, STROBE	GRIMES	33
30-0837-19	LIGHT, STROBE	GRIMES	33
30-0837-21	LIGHT, STROBE	GRIMES	33
30-0837-23	LIGHT, STROBE	GRIMES	33
30-0837-25	LIGHT, STROBE	GRIMES	33
30-0837-27	LIGHT, STROBE	GRIMES	33
30-0837-29	LIGHT, STROBE	GRIMES	33
30-0837-3	LIGHT, STROBE	GRIMES	33
30-0837-31	LIGHT, STROBE	GRIMES	33
30-0837-33	LIGHT, STROBE	GRIMES	33
30-0837-35	LIGHT, STROBE	GRIMES	33
30-0837-37	LIGHT, STROBE	GRIMES	33
30-0837-39	LIGHT, STROBE	GRIMES	33
30-0837-41	LIGHT, STROBE	GRIMES	33
30-0837-43	LIGHT, STROBE	GRIMES	33
30-0837-45	LIGHT, STROBE	GRIMES	33
30-0837-5	LIGHT, STROBE	GRIMES	33



## B737 Component Support Capabilities

Derco Repair Services, Inc.  
 8065 West Fairlane Avenue Milwaukee, WI 53223 USA  
 tel: (414) 355-7770; fax: (414) 355-2648  
 repair@dercoaerospace.com

PART NUMBER	DESCRIPTION	MANUFACTURER	ATA
30-0837-7	LIGHT, STROBE	GRIMES	33
30-0837-9	LIGHT, STROBE	GRIMES	33
30-1401-11	LIGHT, STROBE	GRIMES	33
30-1401-13	LIGHT, STROBE	GRIMES	33
30-1401-15	LIGHT, STROBE	GRIMES	33
30-1401-3	LIGHT, STROBE	GRIMES	33
30-1401-5	LIGHT, STROBE	GRIMES	33
30-1401-7	LIGHT, STROBE	GRIMES	33
30-1401-9	LIGHT, STROBE	GRIMES	33
320115	VALVE, ENGINE ANTI-ICE	WHITTAKER CONTROLS	75
3605812-1	STARTER, APU, ELECTRICAL	HONEYWELL	49
3605812-12	STARTER, APU, ELECTRICAL	HONEYWELL	49
3605812-13-1	STARTER, APU, ELECTRICAL	HONEYWELL	49
3605812-16	STARTER, APU, ELECTRICAL	HONEYWELL	49
3605812-17	STARTER, APU, ELECTRICAL	HONEYWELL	49
3605812-18	STARTER, APU, ELECTRICAL	HONEYWELL	49
3605812-18-1	STARTER, APU, ELECTRICAL	HONEYWELL	49
3605812-19	STARTER, APU, ELECTRICAL	HONEYWELL	49
3605812-2	STARTER, APU, ELECTRICAL	HONEYWELL	49
3605812-21	STARTER, APU, ELECTRICAL	HONEYWELL	49
3605812-22	STARTER, APU, ELECTRICAL	HONEYWELL	49
3605812-3	STARTER, APU, ELECTRICAL	HONEYWELL	49
3605812-4	STARTER, APU, ELECTRICAL	HONEYWELL	49
3605812-9	STARTER, APU, ELECTRICAL	HONEYWELL	49
371380	PUMP, HYDRAULIC	VICKERS	29
372697-13	STARTER, APU, ELECTRICAL	HONEYWELL	49
372697-18-1	STARTER, APU, ELECTRICAL	HONEYWELL	49
372697-22	STARTER, APU, ELECTRICAL	HONEYWELL	49
372697-24	STARTER, APU, ELECTRICAL	HONEYWELL	49
372697-6	STARTER, APU, ELECTRICAL	HONEYWELL	49
372697-9	STARTER, APU, ELECTRICAL	HONEYWELL	49
375322-10	STARTER, APU, ELECTRICAL	HONEYWELL	49
375322-7	STARTER, APU, ELECTRICAL	HONEYWELL	49
375322-8	STARTER, APU, ELECTRICAL	HONEYWELL	49
375322-9	STARTER, APU, ELECTRICAL	HONEYWELL	49
383152-16-1	STARTER, AIR TURBINE	HONEYWELL	80
383152-19-1	STARTER, AIR TURBINE	HONEYWELL	80
39-353	VALVE, ANTI-SKID	CRANE/HYDRO-AIRE	32
40-0135-3	LIGHT, NAVIGATIONAL	GRIMES	33
40-0135-4	LIGHT, NAVIGATIONAL	GRIMES	33
40-0173-1	LIGHT, NAVIGATION	GRIMES	33
40-0173-2	LIGHT, NAVIGATION	GRIMES	33
40-0196-11	LIGHT, ROTATING WARNING	GRIMES	33
40-0196-13	LIGHT, ROTATING WARNING	GRIMES	33
40574	ACTUATOR, FUEL VALVE	J.C. CARTER	28
40574-4	ACTUATOR, FUEL VALVE	J.C. CARTER	28



## B737 Component Support Capabilities

Derco Repair Services, Inc.  
 8065 West Fairlane Avenue Milwaukee, WI 53223 USA  
 tel: (414) 355-7770; fax: (414) 355-2648  
 repair@dercoaerospace.com

PART NUMBER	DESCRIPTION	MANUFACTURER	ATA
45-0083-1	LIGHT, LANDING	GRIMES	33
45-0083-2	LIGHT, LANDING	GRIMES	33
45-0083-3	LIGHT, LANDING	GRIMES	33
45-0083-5	LIGHT, LANDING	GRIMES	33
45-0083-7	LIGHT, LANDING	GRIMES	33
4663-8	VALVE, NIPPLE, CHECK	KAISER	36
4812-70	MOTOR, FILTER ASSEMBLY	MONOGRAM	
48363-1-1	STARTER, APU, ELECTRICAL	GARRETT	49
48363-1-3	STARTER, APU, ELECTRICAL	GARRETT	49
541674	ACTUATOR, RAM AIR DOOR	HONEYWELL	21
541674-1	ACTUATOR, RAM AIR DOOR	HONEYWELL	21
541674-1-1	ACTUATOR, RAM AIR DOOR	HONEYWELL	21
541674-3	ACTUATOR, RAM AIR DOOR	HONEYWELL	21
541674-4	ACTUATOR, RAM AIR DOOR	HONEYWELL	21
541674-5	ACTUATOR, RAM AIR DOOR	HONEYWELL	21
541674-6	ACTUATOR, RAM AIR DOOR	HONEYWELL	21
55097	PUMP, HYDRAULIC	ABEX	29
55097-01	PUMP, HYDRAULIC	ABEX	29
55097-02	PUMP, HYDRAULIC	ABEX	29
55097-03	PUMP, HYDRAULIC	ABEX	29
55098-01	PUMP, HYDRAULIC	ABEX	29
569653	PUMP, HYDRAULIC	VICKERS	29
57186	PUMP, HYDRAULIC ELECTRIC	PARKER	29
57186-01	PUMP, HYDRAULIC ELECTRIC	PARKER	29
57186-02	PUMP, HYDRAULIC ELECTRIC	PARKER	29
57186-03	PUMP, HYDRAULIC ELECTRIC	PARKER	29
57186-04	PUMP, HYDRAULIC ELECTRIC	PARKER	29
57186-05	PUMP, HYDRAULIC ELECTRIC	PARKER	29
57186-06	PUMP, HYDRAULIC ELECTRIC	PARKER	29
57186-07	PUMP, HYDRAULIC	PARKER	29
57186-10	PUMP, HYDRAULIC	PARKER	29
60128	VALVE, FUEL SHUTOFF	J.C. CARTER	28
605675-1	FAN, VANEAXIAL	HONEYWELL	21
60857-3	ACCUMULATOR, HYDRAULIC	TELEDYNE	29
60857-5	ACCUMULATOR, HYDRAULIC	TELEDYNE	29
60896	ACCUMULATOR, HYDRAULIC	TELEDYNE	29
60896-3	ACCUMULATOR, HYDRAULIC	TELEDYNE	32
60896-4	ACCUMULATOR, HYDRAULIC	TELEDYNE	32
60896-5	ACCUMULATOR, HYDRAULIC	TELEDYNE	32
61163	VALVE, FUEL SHUTOFF	J.C. CARTER	28
61185	VALVE, FUEL SHUTOFF	J.C. CARTER	28
65-44651-10	ACTUATOR, SLAT	BOEING	27
65-44651-11	ACTUATOR, SLAT	BOEING	27
65-44651-12	ACTUATOR, SLAT	BOEING	27
65-44651-13	ACTUATOR, SLAT	BOEING	27
65-44651-14	ACTUATOR, SLAT	BOEING	27



## B737 Component Support Capabilities

Derco Repair Services, Inc.  
 8065 West Fairlane Avenue Milwaukee, WI 53223 USA  
 tel: (414) 355-7770; fax: (414) 355-2648  
 repair@dercoaerospace.com

PART NUMBER	DESCRIPTION	MANUFACTURER	ATA
65-44651-15	ACTUATOR, SLAT	BOEING	27
65-44651-16	ACTUATOR, SLAT	BOEING	27
65-44651-17	ACTUATOR, SLAT	BOEING	27
65-44651-6	ACTUATOR, SLAT	BOEING	27
65-44651-7	ACTUATOR, SLAT	BOEING	27
65-44651-8	ACTUATOR, SLAT	BOEING	27
65-44651-9	ACTUATOR, SLAT	BOEING	27
65-44691-3	MODULE, MLG, HYDRAULIC	BOEING	32
65-44691-4	MODULE, MLG, HYDRAULIC	BOEING	32
65-44691-5	MODULE, MLG, HYDRAULIC	BOEING	32
65-44691-6	MODULE, MLG, HYDRAULIC	BOEING	32
65-44751-2	ACTUATOR, ELEVATOR TABLOCK	BOEING	27
65-44810	ACTUATOR, MLG UPLOCK	BOEING	32
65-44810-3	ACTUATOR, MLG UPLOCK	BOEING	32
65-44810-4	ACTUATOR, MLG UPLOCK	BOEING	32
65-44810-5	ACTUATOR, MLG UPLOCK	BOEING	32
65-44810-6	ACTUATOR, MLG UPLOCK	BOEING	32
65-44825	ACTUATOR, MLG UPLOCK	BOEING	32
65-44851	ACTUATOR, GROUND SPOILER	BOEING	27
65-44851-10	ACTUATOR, GROUND SPOILER	BOEING	27
65-44851-12	ACTUATOR, GROUND SPOILER	BOEING	27
65-44851-13	ACTUATOR, GROUND SPOILER	BOEING	27
65-44851-14	ACTUATOR, GROUND SPOILER	BOEING	27
65-44851-3	ACTUATOR, GROUND SPOILER	BOEING	27
65-44851-4	ACTUATOR, GROUND SPOILER	BOEING	27
65-44851-5	ACTUATOR, GROUND SPOILER	BOEING	27
65-44851-6	ACTUATOR, GROUND SPOILER	BOEING	27
65-44851-7	ACTUATOR, GROUND SPOILER	BOEING	27
65-44951-6	ACTUATOR, GROUND SPOILER R/	BOEING	27
65-44951-7	ACTUATOR, GROUND SPOILER L/H	BOEING	27
65-44960-10	ACTUATOR, OUTBOARD GROUND	BOEING	27
65-44960-11	ACTUATOR, OUTBOARD GROUND	BOEING	27
65-44960-13	ACTUATOR, OUTBOARD GROUND	BOEING	27
65-44960-15	ACTUATOR, OUTBOARD GROUND	BOEING	27
65-44960-2	ACTUATOR, OUTBOARD GROUND	BOEING	27
65-44960-28	ACTUATOR, OUTBOARD GROUND	BOEING	27
65-44960-29	ACTUATOR, OUTBOARD GROUND	BOEING	27
65-44960-30	ACTUATOR, OUTBOARD GROUND	BOEING	27
65-44960-4	ACTUATOR, OUTBOARD GROUND	BOEING	27
65-44960-5	ACTUATOR, OUTBOARD GROUND	BOEING	27
65-44960-6	ACTUATOR, OUTBOARD GROUND	BOEING	27
65-44960-8	ACTUATOR, OUTBOARD GROUND	BOEING	27
65-44960-9	ACTUATOR, OUTBOARD GROUND	BOEING	27
65-44961-10	ACTUATOR, OUTBOARD GROUND	BOEING	27
65-44961-12	ACTUATOR, OUTBOARD GROUND	BOEING	27
65-44961-14	ACTUATOR, OUTBOARD GROUND	BOEING	27



## B737 Component Support Capabilities

Derco Repair Services, Inc.  
 8065 West Fairlane Avenue Milwaukee, WI 53223 USA  
 tel: (414) 355-7770; fax: (414) 355-2648  
 repair@dercoaerospace.com

PART NUMBER	DESCRIPTION	MANUFACTURER	ATA
65-44961-16	ACTUATOR, OUTBOARD GROUND	BOEING	27
65-44961-2	ACTUATOR, OUTBOARD GROUND	BOEING	27
65-44961-3	ACTUATOR, OUTBOARD GROUND	BOEING	27
65-44961-4	ACTUATOR, OUTBOARD GROUND	BOEING	27
65-44961-5	ACTUATOR, OUTBOARD GROUND	BOEING	27
65-44961-6	ACTUATOR, OUTBOARD GROUND	BOEING	27
65-44961-7	ACTUATOR, OUTBOARD GROUND	BOEING	27
8921082G1	HEATER, WATER	BF GOODRICH	38
8921082G2	HEATER, WATER	BF GOODRICH	38
8921082G5	HEATER, WATER	BF GOODRICH	38
90-0220-1	WIPER, ELECTRIC	GRIMES	30
90-0220-3	WIPER, ELECTRIC	GRIMES	30
90G183	SWITCH, PRESSURE	CUSTOM CONTROL SENSO	29
939D150-2	REGULATOR, VOLTAGE	HAM-STD	24
976J449-1	GENERATOR, AC	HAM-STD	24
976J498-1	GENERATOR, AC	HAM-STD	24
976J498-1R	GENERATOR, AC	HAM-STD	24
976J498-2	GENERATOR, AC	HAM-STD	24
976J598-1	GENERATOR, AC	HAM-STD	24
A61446-1	VALVE, NOSE GEAR	CRANE/HYDRO-AIRE	29
A61446-2	VALVE, NOSE GEAR	CRANE/HYDRO-AIRE	29
A61446-3	VALVE, BYPASS	CRANE/HYDRO-AIRE	29
A61446-4	VALVE, NOSE GEAR	CRANE/HYDRO-AIRE	29
AG1012AA03	LIGHT, RECOGNITION	HONEYWELL	33
AG1027AA01	LIGHT, RECOGNITION	HONEYWELL	33
AP10V-68	PUMP, HYDRAULIC	ABEX	29
AP10V-68-01	PUMP, HYDRAULIC	ABEX	29
AP10V-68-02	PUMP, HYDRAULIC	ABEX	29
AP10V-68-03	PUMP, HYDRAULIC	ABEX	29
AP10V-78	PUMP, HYDRAULIC	ABEX	29
AP10V-78-01	PUMP, HYDRAULIC	ABEX	29
AP10V-78-02	PUMP, HYDRAULIC	ABEX	29
AP10V-78-03	PUMP, HYDRAULIC	ABEX	29
AP10V-7B	PUMP, HYDRAULIC	ABEX	29
AP10V-7B-01	PUMP, HYDRAULIC	ABEX	29
AP10V-7B-02	PUMP, HYDRAULIC	ABEX	29
AV13J5100	VALVE, HYDRAULIC	ITT AEROSPACE	29
AV13J5101	VALVE, HYDRAULIC	ITT AEROSPACE	29
AV13J5103	VALVE, HYDRAULIC	ITT AEROSPACE	29
AV13J5105	VALVE, HYDRAULIC	ITT AEROSPACE	29
AV13J5144	VALVE, HYDRAULIC	ITT AEROSPACE	29
AV13J5147	VALVE, HYDRAULIC	ITT AEROSPACE	29
AV13J5156	VALVE, HYDRAULIC	ITT AEROSPACE	29
AV16B1350	VALVE, HYDRAULIC	ITT AEROSPACE	29
AV16E1209D	VALVE, FUEL, SHUTOFF	ITT AEROSPACE	28
AV24E1144	VALVE, BALL	ITT AEROSPACE	29



## B737 Component Support Capabilities

Derco Repair Services, Inc.  
8065 West Fairlane Avenue Milwaukee, WI 53223 USA  
tel: (414) 355-7770; fax: (414) 355-2648  
repair@dercoaerospace.com

PART NUMBER	DESCRIPTION	MANUFACTURER	ATA
AV24E1144-2	VALVE, BALL	ITT AEROSPACE	29
MF9-3911-25Z	MOTOR, HYDRAULIC	VICKERS	27
MF9-3911-30ZE	MOTOR, HYDRAULIC	VICKERS	32
MS-3911-30ZE-4C	MOTOR, HYDRAULIC	VICKERS	27
MS9-3911-30ZE	MOTOR, HYDRAULIC	VICKERS	27
S283T001-10	TRANSDUCER, WHEEL SPEED	BOEING	32
S283T001-15	TRANSDUCER, WHEEL SPEED	BOEING	32
ST-104Z	TRANSMITTER, OIL PRESSURE	AMETEK	31
ST-107R	TRANSMITTER, HYDRAULIC	AMETEK	29
ST-107R-M1	TRANSMITTER, HYDRAULIC	AMETEK	29
XW20548-M1	MOTOR, ELECTRIC WINDSHIELD	BF GOODRICH	30